




# TOP AND CABINET PARTS

For Model: LSW9700PQ2  
(Designer White)

AUTOMATIC WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CABINET PARTS

For Model: LSW9700PQ2

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3958075	Installation Instructions
	3955919	Feature Sheet
	8578232	Use & Care Guide
	3957481	Energy Guide
	8564019	Wiring Diagram

## Following May Be Purchased

### DO-IT-YOURSELF REPAIR MANUALS


	4313896	Do-It-Yourself Manual (Washer)
2	8318064	Top
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push-In (2)
5	63424	Cabinet
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3362952	Dispenser, Bleach
8	3351614	Screw, Ground
9	3976348	Cabinet-Sound Damper
10	3357011	Screw, 10-16 x 1/2
11	8318084	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	8318088	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19	8542387	Lid
20	9724509	Bumper, Lid (2)
28	3390631	Screw, 10-16 x 3/8 (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS

For Model: LSW9700PQ2

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS

For Model: LSW9700PQ2

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	17	8318046	Clip, Capacitor	36	3400818	Screw, Timer Mounting
2	3400073	Screw, Ground	18	3979347	Valve, Water Inlet & Thermistor Assy.	37	3949187	Switch, Rotary
3		Hose, Water Inlet	19	303294	Edge Protector	39	3956584	Panel, Console
	8571377	Blue Coupler	20	8572717	Capacitor, Motor Start	42	8536939	Clip, Knob
	8571378	Red Coupler	21	301958	Clamp, Hose	44	8544943	Knob, Timer
4	9740848	Screw, 8-18 x 1/2	22	8317974	Hose, Vacuum Break	45	8544947	Dial, Timer
5	8568314	Strap, Console (2)	23	370450	Clamp, Hose	46	8544935	Knob, Control
6	8318015	Panel, Rear	24	387606	Break, Vacuum	47	3347868	Cable Tie
7	62747	Pad, Rear Panel	25	8055003	Clip, Harness & Pressure Hose	49	388326	Screw, 8-18 x 1.25 (Panel to Top)
8	8559373	Drain Hose Assembly (Includes Illus. Nos. 27 & 28)	26	8519200	Support, Rear Panel	50	62863	Screw, 10-16 x 3/8
9	8557301	Timer, Control (60 Hz.) (Motor Not A Service Part)	27	8541667	Clamp, Hose	51	8271359	Cap, End (R.H.)
10	3351614	Screw, Ground	28	8541668	Clamp, Hose	53	8541672	U-Bend, Drain Hose
11	90767	Screw, 8-18 x 3/8	29	8317975	Retainer, Harness	55	8539874	Shield, Suds
12	8528337	Switch, Water Level	30	3363366	Clamp, Hose	56	3957275	Harness, Wiring (For Detail See Pages 9 & 10)
13	3948608	Bracket, Control	31	8317496	Clamp, Hose			
14	661661	Cord, Power (Includes Illus. 15)	32	3951449	Hose, Pump To Tub			
15	3952821	Strain Relief, Power Cord	33	8541669	Bucket, Drain Hose (Left Half)			
16	8271365	Cap, End (L.H.)	34	8541658	Bucket, Drain Hose (Right Half)			
			35	8571736	Switch, Water Temperature (ATC)			

## FOLLOWING PARTS NOT ILLUSTRATED


3957361 Miscellaneous Parts Bag

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AGITATOR, BASKET AND TUB PARTS

For Model: LSW9700PQ2

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AGITATOR, BASKET AND TUB PARTS

For Model: LSW9700PQ2

(Designer White)


Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser, Fabric Softener
2	358237	Screw & Washer (5/16-24 x 1)
3	3363003	Clothes Mover
4	3951632	Agitator
5	8528150	Tub Ring & Gasket
6	3976308	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	8543666	Washer, Agitator
9	3951682	Cam Driven
10	3366877	Dog, Agitator Clutch (4)
11	3952374	Bearing-Driven Cam
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring
15	3949550	Washer
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	3951744	Agitator Asy. (Complete)
21	8519788	Balance Ring
22	3951608	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
25	2219077	Clip, Pressure Switch Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS


For Model: LSW9700PQ2

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 12 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 13 For Further Breakdown)
10	3357334	Screw, Gearcase To Base (2)

Illus. No.	Part No.	DESCRIPTION
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor & Isolation
14	8577374	Seal
15	3355454	Clip, Anti-Rattle
16	3400516	Screw (2)
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528157	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MACHINE BASE PARTS

For Model: LSW9700PQ2

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	8575214	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus. 6, 7, 8, 9, 18 & 26)
21	3359452	Nut, Lock (2) (3/8-16)
22	389102	Foot, Front (2)
23	8577376	Seal, Centerpost
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# WIRING HARNESS PARTS

For Model: LSW9700PQ2

(Designer White)



WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

For Model: LSW9700PQ2

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	10	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)	17	3347730	Receptacle (6-Way) (Use Term. 94613)
2	388498	Clip, Harness				18	3349494	Connector, Etc
3	3347812	Clip, Harness	11	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	19	3407125	E.T.C. Control
4	3352501	Clip, Harness	12	3347243	Block, Disconnect (Use Term. 352088)	20	3948617	Connector (T.P.A.) (3-Circuit) (Lid Switch)
5	90016	Clip, Harness	13	63523	Protector	21	3360056	Connector (T.P.A.) (3-Circuit) (Pressure Switch)
6	3390496	Clip, Harness	14	717252	Connector (2-Way) (Use Term.94614)	22		Block, Connector
7	389379	Retainer, (Suds Models) Timer, Block Disconnect	15	3352944	Clip, Harness		3354925	Cold Valve
8			16	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)		3354926	Hot Valve
	3948614	White						
	352089	Black						
9	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)						

**FOR COMPLETE WIRING HARNESS REFER TO  
CONTROL AND REAR PANEL PARTS PAGE**




WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WATER SYSTEM PARTS

For Model: LSW9700PQ2

(Designer White)



WS400


Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BRAKE AND DRIVE TUBE PARTS

For Model: LSW9700PQ2

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	387806	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS  
NOT ILLUSTRATED

285208 Lubricant  
(Use Only In  
Brake Shoe  
Assembly On  
Roller & Pin)


BD-315-B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# GEARCASE PARTS

For Model: LSW9700PQ2

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Model: LSW9700PQ2

(Designer White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

72017 White

## PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray

350930 White

## PAINT, BULK (1 qt.)

799344 White (Uncut)

## OIL

350572 Oil, Gearcase  
(16 Oz.)

## LUBRICANT

285208 Lubricant (Use  
Only in Brake  
Shoe Assembly  
On Roller and  
Pin)

## SEALER

285195 Sealer, Gasket  
(.20 Fl. Oz.) (6 ml)

## ACCESSORY PARTS

367031 Drain Protector  
285320 Siphon Break Kit